

Torrey EQB/EQM/FS Calibration (E16 & After)

- 1.- Turn on the scale.
- 2.- While display show lines, press the next key sequence: TARE, KG/LB, LIGHT, ZERO. Next, Type the code: TARE, ZERO, ZERO, TARE, ZERO, TARE (100101).
- 3.- Press LIGHT (scales shows CAL), Press LIGHT (scale shows Cal Weight), Press LIGHT
- 4- You will see the "ZERO" message, make sure that there's no any object in the scale, then press LIGHT.
- 5.- You will see the "LOAD" message, place the calibration weight on the scale (*), then press LIGHT.
- 6.- Scale shows Cal Factor and then OFF, Turn off the scale.

*Note:

- EQB 50/100 - Calibration Weight = 50 lb.
- EQB 100/200 - Calibration Weight = 100 lb.
- FS 250/500 - Calibration Weight = 100 lb.
- FS 500/1000 - Calibration Weight = 200 lb.
- EQM 200/400 - Calibration Weight = 100 lb.
- EQM 400/800 - Calibration Weight = 200 lb.
- EQM 1000/2000 - Calibration Weight = 400 lb.